

Set-Up Instructions





Thank you for purchasing one of the newest, lightest and most versatile houses on the market. We feel you will be completely satisfied with your purchase.

#### WARRANTY

This product comes with a 1 year warranty for any manufacturer's defects. This warranty does not cover damage or wear from unintended use of the product. Warranty is non-transferable and all claims must be accompanied with an original, dated receipt.

Free replacement windows are provided for the life of the house.

For warranty help please contact KMDA, Inc. by one of the following methods.

**By Phone:** (218) 245-3040, Mon-Fri, 9am to 4pm CST

**By Mail:** KMDA, Inc.

PO Box 509 Bovey, MN 55709

#### LIMITATION OF LIABILTY

KMDA, Inc. is not liable for any injury, loss, damage or expense, direct or consequential, from the use or misuse of this product. Liability is limited to repair and replacement of parts as stated by the terms in the warranty.

## **STEP 1:** Unpack the Fish House

The Stalker Spear-Sight-Angle House come fully assembled from the factory. Set-up is quick and easy and gets faster the more you do it.



Spread the house out on the ground as shown:



### **STEP 2:** Cross the Side Poles:



Slide the bar ends over the top bar and passed the push pin:



**STEP 3:** Raise <u>one</u> side of the house part-way by extending the two poles. Lock them into place with the thumb screw:



**STEP 4:** Fully extend the opposite side poles and lock into place. Return to the first side and extend fully:



The velcro wraps at the crossing point of the two poles can be secured to keep the sides from blowing in if windy.

#### The house is ready to be fished in!

### **STEP 5:** Additional Features:



Each corner of the house has a strap loop for securing the shelter to the ice with anchors or tying off to a ATV, vehicle, etc.

Above the hole are two straps which can be used to hang a line or reel for decoys, etc.



### TAKING DOWN THE FISH HOUSE

 The process for taking down the house is the reverse of the set-up. With time the set-up and take-down will become very quick and easy.

### PRECAUTIONS

To protect your fish house and insure a long life it is important to following these guidelines:

**1. Keep heat sources away from the fabric.** The nylon fabric can melt or lose its protective coating if a heater is too close.

**2.** Be extremely careful with any fabric that becomes frozen to the ice. Pulling fabric that is frozen to the ice will most likely tear. Loosen carefully before pulling.

**3.** Dry out the shelter after each use and before storing. Moisture will reduce the lifespan of any fabric, whereas, a well cared for and dried canvas will last for years.

#### SAFE USE and WARNINGS

Read and follow all instructions for safe use. Failure to do so could result in serious injury or death.



DO NOT USE OPEN FLAME HEATERS IN THIS ICE SHELTER. THE FABRIC IS NOT FIREPROOF AND CAN MELT IF IT CONTACTS A HOT SURFACE.



ASPHYXIATION MAY RESULT FROM OXYGEN DEPLETING HEATERS. MAKE SURE FISH HOUSE VENTS ARE OPEN WHEN IN USE.



DO NOT LEAVE SHELTER UNATTENDED. IF USED AT NIGHT, MAKE SURE THERE ARE REFLECTORS VISIBLE ON ALL SIDES OF THE SHELTER TO PREVENT COLLISIONS.

### **ICE RUNNER ACCESSORIES**

KMDA, Inc. provides many accessories to help you get the most out of your new fish house. We recommend the following items:



Find these items at your local retailer, or visit:

## www.kmdainc.com

For a complete selection of all our great products.



# www.kmdainc.com